Llegrand

adaptable DLP trunking 50 x 150 trunking and fittings







Selection chart (p. 706) Wiring capacity chart (p. 726)

Conform to NF C 68-104

Trunking Angles and end caps (continued) Pack Cat.Nos Pack Cat.Nos 1 comp. Cover 130 2 comp. Cover 65 Suitable for a wide range of requirements and applications: - Distribution: large wiring capacity and wide Α В 106 22 Changeable external angle, from 60° to 120° for $50 \times 80/50 \times 105/50 \times 150$ and 50×195 mm 10 access to the wiring space Installation: can be used with other ranges: Mosaic or Lexic 1 comp. Cover 130 trunkings 106 35 Changeable external angle, 5 Α В **Body** from 60° to 120° for 50 x 150 and 104 32 10(1) 50 x 150 mm 50 x 195 mm trunkings Supplied without cover 90° flat angle 107 89 Length 2 m 5 Flexible covers 107 03 Left or right end cap 10 Fit on to the whole trunking including in internal or external angles Length 2 m **Junctions** 105 21 Partial cover width 65 mm 20(1) 8(1) Flat junctions 105 24 Full cover width 130 mm 5 107 35 To tap-off to an 80 mm wide **Partitions** trunking Length 2 m 48(1) 104 72 Division partition, 107 37 To tap-off to a 105 mm wide 5 for fitting partial covers trunking equipped with a 65 mm 105 82 cover 24(1) Separation partition 5 107 36 To tap-off to a 105 mm wide trunking equipped with an 85 mm Body joint For aligning bases during cover 20 106 91 Angled junction installation To tap-off in an internal angle 5 107 63 to 35 x 80, 35 x 105, 50 x 80 or 20 106 92 Body joint, attached with adhesive (fit at the end of installation) 50 x 105 mm trunking Used with an internal angle 10 108 04 | 108 01 Cover joint Cat.No 106 02 or 106 06 **Accessories** Angles and end caps 1 comp. Cover 130 2 comp. Cover 65 Internal and external angles Α В Include the 2 components for the top and bottom of the trunking and 1 partition junction to ensure continuity of partitions 106 86 50 106 81 1 comp. 2 comp. Cover 130 Cover 65 and to hold the cover in place for the 308.81 Base for clamp 100 Α В 2 compartments trunking only Changeable internal angle, from 85° to 95° for 50 x 80/50 x 105/ 50 x 150 and 50 x 195 mm trunkings 106 02 10 Installation accessories (p. 724) Changeable internal angle, 5 106 06

from 85° to 95° for 50 x 150 and 50 x 195 mm trunkings